



1977 DATSUN 280Z WIRING DIAGRAM

KEY

- ⊙ AUTOMATIC TRANSMISSION MODELS
- ⊙ MANUAL TRANSMISSION MODELS
- ⊙ CALIFORNIA MODELS
- ⊙ FOR U.S.A.
- ⊙ 2 + 2 SEATER
- ⊙ AIR CONDITIONER
- ⊙ HEATER

SWITCH AND RELAY POSITIONS

1. IGNITION SWITCH IN LOCK (KEY REMOVED)
2. LIGHT AND WIPER SWITCH OFF
3. SEATS UNOCCUPIED
4. DOORS CLOSED
5. TRANSMISSION IN NEUTRAL
6. HAND BRAKE RELEASED

CONNECTIONS

- NO CONNECTION
- NORMALLY OPEN
- NORMALLY CLOSED

DISCLAIMER:

THIS DOCUMENT WAS REPRODUCED BY USING THE WIRING DIAGRAM IN A FACTORY SERVICE MANUAL FOR MODEL YEAR 1977 DATSUN 280Z

USED WITH PERMISSION FROM NISSAN MOTOR CO., LTD.

NISSAN MOTOR CO., LTD. IS NOT RESPONSIBLE FOR OMISSIONS, MISTAKES, ERRORS OR CHANGES IN THE REPRODUCTION OF THIS DIAGRAM.

Classic Zcar Club

240z.org & classiczcars.com

©2004 www.classiczcars.com